Velocity NoteMagix M10 A82 DDR RAM Replacement

There are two screws holding in a plate that covers the RAM. Removing the screws and the plate will yield access to the RAM.

Written By: Sam Middleton

INTRODUCTION

This guide will show how to safely remove the RAM from the NoteMagix M10 A82 netbook.

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Battery

- Place the notebook on the table, with the battery facing away from you.
- Slide the switch from "lock" to "unlock" with your right hand on the right side of the computer.
- Maintain holding the right switch in the "unlock" position.
- Use your left hand to slide the left switch from "lock" to "unlock".

Step 2

- Maintain both left and right switches in the "unlock" position.
- Use your forefingers to push the battery out of the computer.

Step 3 — RAM



- Locate the DDR panel and unscrew the two 3.65mm Phillips #1 screws holding it in place.
- Use the spudger to lift the DDR panel off.

Step 4

- Push in the tabs on the sides that contain the RAM.
- Gently raise the RAM up to a 45 degree angle and gently pull the RAM towards you.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2014-10-14 08:58:35 AM.